






Gli accessori della cucina elegante



Cassetti e sottopiani

BOISERIE



Cassetti con movimento elettrico




002




003



004











007



008



009



011



012



001



013



014



015



016



017



018



019



020



18  
021

19


BOURBIE ITALIA








024



025



026




027



028



029



030



031



25



032



033




034



032



036



037



038





039



040

042



043



041



044





045



046



048



047



049



050



053



051



052




054



001



055



056




057




058




059



060



061



062



063



064



065

I porta piatti




066



067



068



069



070



071



072



073



074

Portabottiglie



075



077



078



076



079

I barattoli



080



081





083



**ALTEZZA**  
80 mm

**P.PASTA**  
**DIAMETRO**  
100 mm



**ALTEZZA**  
165 mm

**DIAMETRO**  
100 mm

084



085



086



H  
8 cm  
5 cm  
DIAMETRO

087



088



089



092



090



091



093



094

accessori top

BOISERIE ITALIA





096



100



097



098



101



099



102

Colonne estraibili  
contenitori

BOISERIE





104



105



106



107



108



109



110

Luci


BOISERIE







112



114



113




115



116



117



118


Accessori



119



120



121



122



123



124



127



128



125



126



129



130



131



132



135



136



133



134



137



138



139

